

SAFEBOARD™

ROUGHTOP



Installation Guide

Equipment Needed

- Cutting Tools
- Measurement Tools
- Drill
- SAFEBOARD™ Roughtop Screws
- SAFEBOND Hybrid Adhesive



Step-By-Step Guidelines

SAFEBOARD™ Roughtop is intended to be used as a plywood replacement for countertop subtops. Roughtop is not rated for overhangs.

1. SAFEBOARD™ Roughtop can be cut to size using a skill saw or a table saw. The blade used can be a wood blade or circular saw blade. Be sure to use protective gloves and safety glasses when cutting.
2. Once cut to size, test the fitting of the panel on top of the cabinet to ensure the panel has been cut to the correct size.
3. Once fit is confirmed, SAFEBOND Hybrid Adhesive will be applied to to the cabinet.
4. Map your screw pattern by measuring and marking on the sub-top where you will drive the screws. Evenly space screws 8 to 16 inches apart around the perimeter of the cabinet, and 8 inches from the front of the cabinet to back. Screws must start 2 inches in from the edge.
5. Screw the sub-top down to the frames of the cabinet using SAFEBOARD™ Roughtop Screws (Construction screws are NOT recommended).
 - a. SAFEBOARD™ Roughtop Screws are designed specifically for mounting SAFEBOARD™ Roughtop. The large washer distributes forces that would otherwise harm the foam structure.
6. Bond your stone to Roughtop with a SAFEBOND Hybrid Adhesive.

CONTACT INFORMATION

(805) 626-7333

www.safeboardpro.com

sales@safeboardpro.com

